

MTB brake pads

Fitting Instructions:

Check the correct choice of pads with the manufacturer (type and year of manufacture). The pads must be replaced as soon as the thickness of the braking surface falls below the manufacturer's recommended thickness. Brake surfaces must be protected from grease, oils and other chemicals.

1. Remove the front/rear wheel and old brake pads.
2. Clean the inside of the caliper and brake disc using brake cleaner.
3. Gently push each piston back into the caliper body (e.g. using a flathead screwdriver). Then install the new pads together with the spacer spring.
4. For proper brake performance, the new pads must be driven in thoroughly before riding.

Dispose of the product environmentally at the end of its service life.

Dealer:

MEFO SPORT CENTRUM s.r.o., Jinín 60, 38601 STRAKONICE

www.mefo.cz