

Instructions for using the brake pedal

Installation:

Set the brake pedal in a static position so that it is just horizontal to the footpeg. This will reduce the possibility of the pedal bending and achieve the ideal position for both standing and sitting. Set a clearance of at least 2.5cm on the pedal to avoid overheating the rear brakes. If your foot is too small or too large, consider shortening or lengthening the shifter and brake pedal to the desired distance.

Maintenance:

Keep the teeth on the brake pedal sharp to ensure maximum effect on the shoe. Most motorcycles have steel teeth and these can be adjusted with a hand file. If any wear or damage occurs, the brake pedal must be replaced.

The manufacturer is not responsible for any injuries that may occur.

Dispose of the product in an environmentally friendly manner at the end of its useful life.

Made in the EU

Imported by MEFO SPORT CENTRUM s.r.o., Jinín 60, Strakonice, www.mefo.cz