

Gas handle

WARNING:

This product should be installed by a professional mechanic in accordance with your motorcycle manufacturer's manual. Improper installation could cause injury or death.

Installation. Remove the cover screw and lift the cover and guide wheel . Unscrew the two Allen screws and separate the two halves of the cover and the throttle plastic from each other . Thread the cable through the top of the cover . Wrap the cable around the guide wheel and push the guide wheel back into place. Place the ball roller at the end of the cable into the hole on the throttle cylinder and insert the throttle cylinder into the top of the cover (Pay attention to the correct position of the throttle cylinder . Push the two halves of the cover together and check that the throttle cylinder rotates freely, returns freely and comes to a complete stop at the "at rest" position. The end of the throttle plastic should be parallel to the end of the handlebar. Attach the cover to the designated place and secure with the screw. Rotate the throttle handle to the desired position and evenly fasten the Allen screws while maintaining equal spacing (gaps) between the two halves of the cover on either side of the handlebar. Normally the correct position is that the cable runs across the top and front of the handlebar.

Maintenance:

Periodically check that the throttle handle is securely fastened.

Dispose of the product environmentally at the end of its life.

Made in the EU

MEFO SPORT CENTRUM s.r.o., Jinín 60, Strakonice 38601, www.mefo.cz