

1. Spray the product directly onto the contaminated area.
2. Leave for 1–3 minutes.
3. Wipe away loosened residue using a soft cloth.
4. Repeat if necessary.
5. Wash the surface with water or a motorcycle cleaner afterwards.

Warning

Keep out of reach of children. Avoid contact with eyes and skin. Test on an inconspicuous area before use. Do not use on hot surfaces or in direct sunlight.

Manufacturer www.motoverde.com