

1. Rinse the motorcycle with water to remove loose dirt and debris.
2. Apply Motoverde Snow Foam using a foam lance or foam sprayer.
3. Leave the foam to work for 3–5 minutes.
4. Do not allow the product to dry on the surface.
5. Rinse thoroughly with clean water.
6. For best results, follow with Motoverde Bike Wash.

Warning

Keep out of reach of children. Avoid contact with eyes. Do not apply to hot surfaces or in direct sunlight. Store in a cool, dry place.

Manufacturer www.motoverde.com