

## Instructions for replacing the shifter end cap

Installation: remove the old shifter end cap. Replace the old shifter end cap with the new end cap using the hexagon head bolt and spring.

Maintenance: If any wear or damage occurs, the shifter end cap must be replaced.

Riding the motorcycle can be dangerous. The manufacturer is not responsible for injuries that may occur.

Dispose of the product in an environmentally friendly manner.

Country of origin.

Importer: MEFO SPORT CENTRUM s.r.o., Jinín 60, Strakonice, [www.mefo.cz](http://www.mefo.cz)