

## Vent valves

### WARNING:

This product should be installed by a professional mechanic in accordance with your motorcycle manufacturer's manual. Improper installation could cause injury or death.

### Installation:

Read the instructions carefully before assembly. Place the motorcycle on the stand with the front wheel off the ground. Note: The minimum clearance between the bleeder valve and the handlebars must be 6mm or more. If the handlebars touch the bleeder valve, the valve will remain open at all times or the adapter will be damaged. Unscrew the bleeder screw from the fork, then lubricate the threads with petroleum jelly and screw on the bleeder valve. Tighten the valve until the o-ring is sufficiently compressed. Repeat the same procedure for the other fork. Before each ride, compress the valve to relieve air pressure in the forks.

### Maintenance:

Periodically check that the valve is securely fastened.

Dispose of the product environmentally at the end of its service life.

Made in the EU

MEFO SPORT CENTRUM s.r.o., Jinín 60, Strakonice 38601, [www.mefo.cz](http://www.mefo.cz)